

Hose Connections Cross-Reference Table

All Measurements are Inner Diameter (I.D.)

C O N N E C T I O N P O I N T	Cuff Connecting to Tool		C O N N E C T I O N P O I N T	Hose Type	C O N N E C T I O N P O I N T	Cuff to Vac	C O N N E C T I O N P O I N T	 64686	 61292, 61293, 61294, 61296, 61297
	I.D. of Hose Cuff Connecting to Tool	Hose Cuff Available		Hose Type Available		Hose Type to Vacuum System			
	19 mm (3/4")	 95601		95729  19 mm (3/4")		—			
	32 mm (1-1/4")	 54208		95395  25 mm (1")		 54208			
	25 mm (1")	 54208 + 95895		72748  28 mm (1-1/8")		 72747			
	25 mm (1")	 95396/25-42							
	32 mm (1-1/4")	 72747		94891  32 mm (1-1/4")		 95800			
	25 mm (1")	 72747 + 95895							
	53 mm (2")	 64616							
	32 mm (1-1/4")	 72620							
	32 mm (1-1/4")	 95800							
	25 mm (1")	 95894 (95800+95895)							
	32 mm (1-1/4")	 96004							
	25 mm (1")	 96006 (96004+95895)							
	50 mm (2")	 96580							
	36 mm (1.4")	 96414							
	32 mm (1-1/4")	 96102							
25 mm (1")	 96103								
50 mm (2")	 97051								